

A GENERAL

The 160A+ has a **TEST TIME** key which can be used to set the length of time that the unit runs a prescribed test. The factory default is Continuous. An indication of the elapsed test time (the time since the **RESTART** key was last depressed) is also provided.

- 1 Depress the **TEST TIME** key. The screen reads:



NOTE: The above screen indicates the factory default setting: **CONT** (Continuous). The **MAX** (Maximum) test time is 999 Hours, 59 Minutes, 59 Seconds. The **ELAP'D** (Elapsed) test time (asterisks) is the time since the green **RESTART** key was last depressed; it is also indicated in hours, minutes, and seconds.

- 2 To change the Maximum test time, use either arrow key to move the underline to 999:59:59 MAX.
- 3 Depress the #3 key (near **SET**). The screen reads:



